

Assembly Instructions


Caution : You must read this before you proceed

Care & Maintenance



- | | |
|---|---|
| ⊘  | • Not for commercial use. For residential use only. |
| ✓  | • Furniture may scratch floors. We recommend using furniture pads to protect your floors. |
| ⊘  | • Do not put hot items directly on furniture surface. |
| ⊘  | • Do not clean furniture with harsh cleansers or polish. |
| ⊘  | • Do not place furniture under direct sunlight. |
| ⊘  | • Do not place furniture near heating or cooling vents. |
| ⊘  | • Do not write on furniture without a padded barrier to protect the surface. |
| ⊘  | • Do not place furniture outside . For indoor use only. |
| ⊘  | • Stains may be removed with mild soap solution and damp cloth. |
| ⊘  | • Children should not climb or jump on the furniture. |
- | | |
|---|--|
| ✓  | • Dust and pick-up spills using a clean, non-colored, lint-free cloth. |
|---|--|

Please look in carton for hardware packs and legs.
Sets often ship in multiple boxes and may arrive a day or two apart.

DINING CHAIR
N842P315186



Parts List


Label	Picture	Description	QTY
Ⓐ		Back Frame	1
Ⓑ		Seat Frame	1
Ⓒ		Leg	2

Hardware

Label	Picture	Description	QTY
①		Bolt (8x55mm)	8
②		Spring Washer (8x13mm)	8
③		Flat Washer (8x19mm)	8
④		Allen Key (M4x60mm)	1

Assembly Preparation

Before
Beginning
Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This Chair has multiple parts and may require up to some 30 minutes to assemble. To give you an overview of the chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Attach Seat Frame (B) to the Back Frame (A) by using Bolt (1), Spring Washer (2) and Flat Washer (3) With the Allen Wrench (4)

Step 2



Attach Leg (C) to the Seat Frame (B) by using Bolt (1), Spring Washer (2) and Flat Washer (3) With the Allen Wrench (4)

Step 3 Complete



Your chair is ready for use
The chair can only be used on a flat, level surface.