

Power Lift Chair
Assembly
Instruction



How to use remote control?



Turn on/off the massage function.

You can select different massage parts to enjoy.

You can select different massage mode to enjoy.

Control the massage intensity from low to high.


Turn on/off the heating function.

Select the heating temperature from M1 to M3.


Set a timer for massage from 15mins to 60mins.

How to use charging port outside of right armrest?


Control Panel is for chair lift and reclining function,also has 1 USB-A outlets and 1 USB-C outlet,which can keep your devices charging,such as nearly all smartphone(like iPhone,Samsung...),iPad,headphones,Kindle etc.



Please make sure you've got everyting lists as following before assembly.




A Chair base




B Backrest



C Ear x2




D Left and right armrest



E Power cord




F Remote control




G Power Source

STEP 1


Insert Armrests (D) to the chair base(A),make sure the slots on the armrests fully assemled to the bottom part.



How to get footrest latch down and stand?




How to recline?




STEP 2

Insert Chair Back(B) to the Chair Base(A),make sure the slots on the back fully assembled to the bottom part.




STEP 3

Insert ears(C) to the back(B),make sure the slots on the ears fully assembled to the backrest.




STEP4

No.1 and No.2 wire connect with the backrest and chair base.
No.3 wire connects with backrest and power cord(E).
No.4 wire connects with backrest and remote control(F).
No.5 wire connect the motor and the side button.
No.6 wire connect the motor and power source (G).



NOTE

1: Two same color wires connect.
2: Please connect all wires BEFORE plug power cord and power source into outlet.



FAQ

Q1: Missing parts when received.

A: If you find some parts are missing from the box, please kindly send us messages to let us know the name of missing part regarding to the first page of instructions. We will send replacement to you asap.

Q2: Some parts damaged when arrived.

A: Please send clear photos about damaged part to us as attachment, we will check and offer you best solution soon.

Q3: The chair is stuck on lifting or reclining position, and no response when you press the lifting or reclining button.

A: Please kindly check if the power source (G) are connected well with lift motor. Sometimes the power source (G) may fall off from the motor.

If the connection is good, then check the lift motor if it has some anomaly, like some noise comes out when you press the lift button. If you can make sure the motor is defective, please contact us for replacement.

How to remove the chair ?

Please note that you need to take apart the backrest before.

1.Pull out the ears from the back
2.Pull up the buckles firstly while take the backrest out from the base.
3.Then pull out the arms from the base.

