
Assembly Instruction

CBN132



EN

General Guidelines

- Please read the following instruction carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.


Notes

- The product is intended for indoor use ony. The product must be assembled and used in accordance with the provisions of the manual. Personal injury and/or damage to product may occur if products are used outside of their intended purposes and/or if products have been changed/modified from their original design. The seller does not assume any responsibility or liability with respect to any injury/damage caused by incorrect assembly or improper use.
- Avoid long-term exposure to humid environments to prevent mildew.
- Keep the product away from fire sources and high temperatures. Do not expose the product to direct sunlight.
- Do not place any hot objects on the surface of the product.
- If there are any defective or missing parts after unpacking, please cease assembly immediately and contact us.
- Please assemble the item on a spacious surface and do not place the unwrapped product directly on the ground to avoid product damage.
- Please do not stand or sit on the wooden boards.
- Please wear gloves during the assembly and/or disassembly process to avoid scratches from any sharp edges.
- Please match the corresponding part and fitting based on the part number in the manual.
- If the part does not match with the fitting, please check the piece as specified in this manual.
- During assembly, first loosely align all screws with the corresponding pre-drilled holes and then tighten the screws one by one.
- Periodically inspect screw tightness while the product is in use. If necessary, retighten to ensure structural integrity.
- If you accidentally spill water or another liquid on the surface, immediately wipe clean with a dry towel.
- Please keep the product away from sharp, pointed objects and corrosive substances to prevent product damage.
- Please place this item on level, solid ground during use.


Warnings


- During assembly, keep all small parts out of the reach of children. it may be fatal if swallowed or inhaled.
- Children should not climb or play on the product in order to avoid tipping over the furniture and causing serious injury.
- To avoid the potential dangers of suffocation, please keep all parts and packaging (film, plastic bags, foam, etc.) away from babies and children.
- Keep sharp objects and corrosive items away from the product to avoid any damage or injury.
- Do not shake or move violently during use to avoid tipping over the product.


Parts List(EN)





















Parts List(EN)





















①  1PCS	②  1PCS	③  1PCS	④  1PCS
⑤  1PCS	⑥  1PCS	⑦  1PCS	⑧  1PCS
⑨  4PCS	⑩  2PCS	⑪  1PCS	⑫  1PCS
⑬  1PCS	⑭  2PCS	⑮  1PCS	⑯  1PCS
⑰  2PCS	⑱  3PCS	⑲  3PCS	⑳  2PCS


Parts List(EN)

A  φ6*35mm 52+2PCS	B  φ15*9.5mm 52+2PCS	C  φ8*30mm 34+2PCS
D  Ø3.5*14mm 24+2PCS	E  Ø3.5*25mm 8+2PCS	F  24+2PCS
G  Handle 6sets	H  Mid bend door hinge 8sets	I  Large curved door hinge 4sets
J  28+2 PCS	K  M4 1PCS	


Assembly Stpes(EN)

Step 1



	Ax2pcs
	Bx2pcs


Step 2



	Ax7pcs
	Bx7pcs


Assembly Steps(EN)

Step 3




	Ax7pcs
	Bx7pcs

Step 4




	Ax4pcs
	Bx4pcs
	Cx4pcs

Step 5




Step 6




	Ax4pcs
	Bx4pcs
	Cx4pcs

Step 7




	Ax4pcs
	Bx4pcs
	Cx4pcs

Step 8




Assembly Steps(EN)

Step 9




	Ax4pcs
	Bx4pcs
	Cx4pcs

Step 10




	Ax12pcs
	Bx12pcs
	Cx10pcs

Step 11




	Ax8pcs
	Bx8pcs
	Cx8pcs


Step 12



	Jx28pcs


Step 13







	Ex8pcs

Step 14










Ix4sets

Step 15







DOOR FITTING




To adjust in width



To adjust in height




To adjust in depth





x4

	Ix16pcs
	Gx2sets

Step 16










Hx8sets

Step 17







DOOR FITTING




To adjust in width



To adjust in height




To adjust in depth



x8

	Hx32pcs
	Gx4sets


Step 18



Fixed Rear Side

	Dx24pcs
	Fx24pcs

Step 19




Final


The ways to adjust the door

- Before adjusting the hinge, please check whether the cabinet is skewed.
- If the skew can not be repaired, please remove the anti-tipping device first, then adjust the cabinet to vertical position.
- Please adjust the hinge with the door open.
- Please operate it with more than 2 people, one person holds the door and the other one adjusts the screw.


Components Name



Obvious gaps between doors or Doors don't look closed



1 Turn "internal & external screw" to the right can make the door approach inside.
Please adjust the doors little by little.




※ If the 2 doors are overlap, please turn the "internal & external screw" to the left.

When door is crooked




Please take the following steps to adjust first.

1 Rotate the "front and rear screws" to the left




※ After adjusting the "front and rear screw", the door still does not change, please turn the "internal & external screw" to the right Slightly.


2 Push the door to the cabinet




3 Rotate the "front and rear screws" to the right




When door is leaning




1 Turn "internal & external screw" to the left can make the top of the door tilted outward.







1 Turn "internal & external screw" to the left can make the bottom of the door tilted outward.




When the door is higher on top




1 Turn "up & down screw" to the left



2 Lower the door's height so that 2 doors are of the same height.



3 Turn "up & down screw" to the right



※ If the door is lower on bottom, please lift up the left door slightly on step 2